The console via USB cable to FS330W PC software
The console via IP/Wi-Fi and network to Web Server

FS290B

FS310B

Wi-Fi Alarm Console

Center Monitor
Web Server

FS240B/D

FS222B/D

Console report all event to center monitor
Center can setting console working mode
Center can setting console alarm function
Center save alarm event for view log

- *Applications:*

The FS330W software is designed for PC window OS system connecting to alarm console via IP or USB port, so that PC window software can operate alarm console working mode and control the AC power switch on/off and setting the alarm function.

The FS330W software is designed for Saving/Loading a txt file of the setting program data.

It can also READ/WRITE the setting program data from alarm console.

It can show all alarm events, working mode, temperature lever data, AC power switch turn on number…etc.

FS330W_PC_V1.8-test

FRONTI

FS330W ALARM SERVICE CENTER SYSTEM

EVENT MONITOR, CONTROL AND SETTING CENTER

☐ TCP/IP Mode   IP Address   114.32.51.39   PASSWORD

Not Connected   Port   23   SCAN

| MONITOR | SWITCH | SECURITY | SETUP | EXIT |

F/W Ver.

FS330W_PC_V1.87

	No.	Date	Time	ALARM	Sensor No.	Sensor Name
DISARM 1-13			INT : ****	EXT : ****	POWER SWITCH ON :	-
DISARM 2-13						

	No.	Date	Time	ALARM	Sensor No.	Sensor Name
	55	05 / 23	16 : 33	HOME 2	10 - 15	
	56	05 / 23	16 : 33	HOME 1	10 - 15	
	57	01 / 01	00 : 00	TAMPER ERROR	00 - 00	
	58	01 / 01	00 : 00	DISARM 2	01 - 00	
	59	01 / 01	00 : 00	DISARM 1	01 - 00	
	60	01 / 01	00 : 00	TAMPER ERROR	00 - 00	
	61	01 / 01	00 : 00	TAMPER ERROR	00 - 00	
	62	01 / 01	03 : 20	OPEN SENSOR	74 - 00	
	63	01 / 01	03 : 20	OPEN SENSOR	75 - 00	
	64	01 / 01	03 : 20	OPEN SENSOR	76 - 00	
	65	01 / 01	03 : 19	OPEN SENSOR	77 - 00	
	66	01 / 01	03 : 19	OPEN SENSOR	78 - 00	
	67	01 / 01	03 : 19	OPEN SENSOR	79 - 00	

MONITOR **SWITCH** **SECURITY** **SETUP** **SYSTEM**

FS330W_PC_V1.89

DISARM 1-01   INT : ****   EXT : ****   POWER SWITCH ON :   -

DISARM 2-01

GSM LEVER   ←   ****

FS132 OPEN   1   2   3

TIMER : ON   4   5   6

WORKING DAY   DISARM : 11:05   HOME : 11:07   AWAY : 11:09

7   8   9

HOLIDAY   DISARM : 11:17   HOME : 11:19   AWAY : 11:21

HOLIDAY   1   2   3   4   5   6   7   CE   0   #

MONITOR **SWITCH** **SECURITY** **SETUP** **SYSTEM**